



7	INSERT QUICK KNOBS THROUGH BRACKET, ROTATE 90° AND INTO T-SLOT IN	N					COMMISCOPE, MIC.		
STRAIGHT SECTION WILE INSERTING BRÄCKET INTO EXPRESS EXIT SLOT. ROTATE QUICK KNOBS CLOCKWISE SUCH THAT T-BOLT FLANGES EXTEND INTO						DRAFTER HECTOR UREÑO	TITLE KIT, BRACKET, RESTRAIN (CUSTOMER DRA		
8.	T-SLOT. SEE DETAIL A. TIGHTEN (4) QUICK KNOBS COMPLETELY.					RUBEN ARVILLA	SIZE SCALE DOCUMENT NO. 1147	7583_ADC	
9	ONLY AVAILABLE IN CATALOG FGS-MEXP-E-A/B/F						USTOMER DRAWING	REVISION SHEET 2 OF 5	
150.24.321	2	4	5	6	7	8	9	10	





