



## CRBSK Ladder Rack Butt Splice Kit Instructions

### General

The CRBSK ladder rack butt splice kit is used to secure either two ladder rack sections together and/or most other ladder rack components. Only one kit is required to secure one end of a ladder rack or component installation (one kit for two side channels).

Ordering information is listed below:

Material ID	Description
760083899	CRBSK ladder rack butt splice kit

### How to Contact Us

- To find out more about **CommScope®** products, visit us on the web at <http://www.commscope.com/>
- For technical assistance:
  - Within the United States, contact your local account representative or technical support at 1-800-344-0223. Outside the United States, contact your local account representative or Authorized Business Partner.
  - Within the United States, report any missing/damaged parts or any other issues to **CommScope** Customer Claims at 1-866-539-2795. Outside the United States, contact your local account representative or Authorized Business Partner.

### Parts List

Verify parts against the parts list below:

Quantity	Description
4	Butt splice ladder clamps
2	3/8-16 x 2-1/4 carriage bolt
2	3/8-16 hex nut
2	3/8" lock washer
1	Instruction sheet

### Tools Required

- 3/8" socket and driver or open-end wrench

### Installation

Position the butt splice ladder clamps over and under the two ladder sections as shown. Use the 3/8"-16 carriage bolt, lock washer and hex nut to secure the two ladder sections together.

