

CTU strength member fixation removal

1 Removing the CTU strength member fixation

Remove the strength member fixation when using cables without strength member or aramid yarn.

