COMMSCOPE[®]

Installation Instructions


TC-1469-IP Rev. B, September 2022

NOVUX™ Fiber Optic System NVX-CR-SA-SM-NN: Cable retention – Rigid strength member

1 Cable diameter range




2 Tools



- Cable stripping and cleaning tools
- Scissors
- Phillips screw driver
- Cable Tie Gun (optional)

3 Kit contents




N°	Description	Qty
1	Carrier	1
2	Strength member connector with screw	1
3	Cable ties	2
4	Silicone tape (1,25 cm / 0.5 Inches width)	1


© 2022 CommScope, Inc. All Rights Reserved

page 1 / 4

All trademarks identified by [®] are registered trademarks in the US and may be registered in other countries. All third party product names, trademarks and registered trademarks are property of their respective owners. This product may be covered by one or more U.S. patents or their foreign equivalents. For patents, see www.cs-pat.com. This document is not intended to modify or supplement any specifications or warranties relating to CommScope products or services. Visit our website or contact your local CommScope[®] representative for more information. www.commscope.com. For technical assistance, customer service, or to report any missing/damaged parts, visit us at: http://www.commscope.com/SupportCenter.



N.°	Description	Preparation
1	Jacket	 Attention: The distance of the jacket that should be removed is depending on the closure where the cable retention is installed. Distances below are valid for cable stubs: CC 100: 130 ±5 cm / 51 ±2 Inches CC 150: 135 ±2,5 cm / 53 ±1 Inch CC 200: 135 ±2,5 cm / 53 ±1 Inch SRC 100: 90 ±5 cm / 35 ±2 Inches SRC 50: 130 ±5 cm / 51 ±2 Inches
2	Dual jacket (if present)	Make the dual jacket as small as possible; keep a maximum length of 1,2 cm / 0.47 Inches. Remove the aramid yarn inside this second jacket.
3	Rigid strength member	Cut the rigid strength member to length to 4,5 +0/-0,5 cm / 1.7 +0/-0.2 Inches). The maximum diameter of the strength member is 3,5 mm / 0.14 Inches.
4	Subunits	Clean the subunits, remove all grease. The subunit tube should be removed to access the fiber. Attention: Stripping point of the subunit is provided in the clo-
		sure installation instructions.




1 Use the strip silicone tape provided in the kit: 6,5 X 1,25 cm / 2.56 X 0.5 Inches.


Attention: Make sure your hands are clean and degreased before preparing and installing the cables. Degrease the cable where the cable will enter the closure.

- 2 Make a mark on the cable 2 cm / 0.79 Inches from the jacket end.
- 3 Apply the silicone tape between the mark and the jacket end. Remove the protective paper. Stretch the tape minimum 50% while wrapping the tape around the cable. First apply a full turn around the cable, then continue to cover up to the jacket end. Make one turn at the end point and come back with the remaining tape.

Install strain relief on drop cable




- 1 Slide the strength member connector onto the carrier until you hear a clicking sound.
- 2 Install the cable ties in the slots in the carrier, as shown. Make sure the teeth of the cable tie are facing upwards.
- 3 Slide the rigid strength member in the strength member connector between the metal spring and the housing of the strength member connector. Verify the strength member fits all the way to the end of the lug.




- 4 Secure the screw with a Phillips screw driver.
- 5 Tighten the two cable ties, make sure the cable tie head is positioned on top of the cable as shown in figure 5 above. A cable tie gun can be used. The recommended force is 85N. Cut of excess cable tie strap.

6 Install drop cable

To secure the cable to the organizer, the three hooks on the rear side of the carrier should slide into the 3 slots on the interface plate on the organizer. The top left slot has a locking lip to keep the cable - carrier assembly in place.






- 1 Slide the carrier with the cable secured into the slots of the organizer. Push the locking lip in the first slot backwards.
- 2 Slide the carrier downwards.

7

3 The locking lip returns into its original position and the carrier is correctly seated. A clicking sound is observed.

Remove carrier



- 1 Position the fiber guidance pen in the little cavity in the locking lip of the first slot and push the locking lip backwards. When the lock is released, lift the carrier up.
- 2 Move the carrier with cable attached forward.