

Installation Guide for CMAX-xxx Antennas CMAX-DM22S-43-V53, CMAX-DM22S-D-V53, CMAX-DM30-43-V53,


CMAX-DM60-43-V53, CMAX-DM30-43-UWI53, CMAX-DM60-43-UWI53, CMAX-DMW3030-43I53

Note:

Please read the complete description before starting the installation. Be sure that connectors are properly sealed from water if no cables are connected to them after installation.

Tools required: Wrench, width: 13 mm


1. Assembly




Fit the 3 parts together and fasten with screws M8 x 16, washers, and spring washers (M8 torque: 27 Nm).



2. Wall Mounting






- 1. Mark 4 holes onto the wall as shown in the drawing above.
- 2. Drill 4 holes into the wall and insert appropriate dowels into holes.
- 3. Attach the antenna pedestal.

3. Pole Mounting (200 mm max. pole diameter)

3.1. Pole Mounting with Lashing Straps (suggestion)

Note:

This pole mounting procedure is for reference only. Other than the shown pole mounting material can be used to mount bracket and antenna to a pole. Make sure the installation will safely support the combined load of the bracket, antenna, and connected cables.




- 1. Lay proper lashing straps around pole and lead them through mounting bracket.
- 2. Adjust bracket in antenna direction and fasten bracket.



3.2. Optional Pole Mounting Kit

Optionally, a pole-mounting kit can be ordered separately from the supplier (ID 7814722). The recommended pole diameter for this mounting kit is 60 - 150 mm. To mount an antenna to a pole using this kit, proceed as follows:




- 1. Insert the four bolts M8x200 (2) with four of the filet washers (5) into the antenna mounting bracket (see detailed illustration of bolt head).
- 2. Insert the pole mounting bracket into these four bolts and place the filet & spring washers (4 & 5) and the M8 nuts (3) over each bolt (detailed illustration).
- 3. Tighten the four M8 nuts observing the specified torque of 27 Nm.
- 4. Hang in the safety wire (6) and attach it to a suitable structure for fall protection.




4. Antenna Mounting

4.1. DM60 Antenna Mounting




Attach antenna and fasten it with washers and M8 nuts (M8 torque: 27 Nm).

4.2. DM22S/DM30 Antenna Mounting



Depending on space available and adjusting angle, the DM22S/DM30 antenna can be mounted onto the pedestal in 3 alternatives (see circle marks in picture to the left-hand side).


4.3. DMH3030/DMW3030 Antenna Mounting



Attach antenna and fasten it with washers and M8 nuts (M8 torque: 27 Nm).




4.4. CMAX-3030/30/60-43-US Antenna Mounting



Attach antenna and fasten it with washers and M8 nuts (M8 torque: 27 Nm).

4.5. Azimuth Angle




- Loosen the 3 fixing screws. (Do NOT unscrew them completely.)
- 2. Adjust your desired angle.

 The complete antenna pedestal can be swiveled to the left- / right-hand side by up to 55°.
- 3. Tighten the fixing screws.



4.6. Elevation Angle




- Loosen the 4 fixing screws at the left- and right-hand side. (Do NOT unscrew them completely.)
- Adjust your desired angle.
- 3. Tighten fixing screws.






4.7. Antenna Cable




4.8. Outdoor Installation

NOTICE: For outdoor use, the antenna must be mounted bottom down, i.e. drain holes showing to the ground. Otherwise, water might penetrate into the antenna and damage it. To indicate top and bottom, an arrow at the rear side of the antenna points to the top:



Note: For outdoor use, we recommend removing the plugs from the drain holes if the antenna is exposed to high humidity or rainfall.

To do so, remove the plugs from the drain holes (up to four) at the bottom of the antenna with a knife or a flat screwdriver. The below illustration shows the location of the drain holes, design and/or size of the antenna may be different.





List of Changes

J	• • • • • • • • • • • • • • • • • • •		
Version	Changes	Release Date	
M0149APB		04-May-2020	
M0149APC	List of antenna types in header updated Notice in chapter 4.8 updated	20-December-2022	

© Copyright 2022 CommScope, Inc.

All rights reserved.

All information contained in this manual has been revised thoroughly. Yet CommScope accepts no liability for any omissions or faults. CommScope reserves the right to change all hardware and software characteristics without notice.

Names of products mentioned herein are used for identification purposes only and may be trademarks and / or registered trademarks of their respective companies.

No parts of this publication may be reproduced, stored in a retrieval system, transmitted in any form or by any means, electronical, mechanical photocopying, recording or otherwise, without prior written permission of the publisher.

CommScope, 20-December-2022